


Opening a SLICK (ignition) magnet 4230 / 4330

Öffnung eines SLICK Zündmagnetes

Ouverture d'une magnéto SLICK



Slick magnet

English

This set of pictures shows how to disassemble and re-assemble a SLICK 4230 or 4330 ignition magnet. This is sufficient to replace or exchange the ignition coil or the capacitor. These steps are so complicated that only a certified company (Aviation Maintenance Company) is allowed to carry out these modifications on certified airplanes.

Deutsch

Diese Fotoserie zeigt wie ein Zündmagnet 4230 oder 4330 geöffnet und geschlossen wird. Dies genügt um die Zündspule oder den Kondensator auszutauschen. Diese Schritte sind so kompliziert, dass nur ein zertifizierter Betrieb (LTB) so etwas für ein zugelassens Flugzeug machen darf.

Français

Cette série de photos montre chaque pas du démontage/remontage d'une magnéto SLICK 4230 ou 4330. Ceci suffit pour l'échange de la bobine ou du condensateur. Cette opération est si compliquée, seule une station homologuée (UEA) a le droit de la faire sur avion certifié.